
Ultra-small, power/signal contact design for Board-to-Board/FPC-to-Board providing 3A max current

BM29 Series




■Features


1. Space-saving design


Compact and flexible design ideal for mobile devices. (Fig.1)


•Pitch: 0.35mm, Depth: 1.5mm, Stacking height: 0.6mm

- 2. Equipped with power contacts capable of handling up to 3A current. (Fig.2)
 - ·Rated current : 3A (power contact), 0.3A (signal contact)
- 3. The proprietary metal guide prevents the connector from being damaged against offset mating. (Fig.3)
- 4. A tactile click ensures secure mating. (Fig.4)
- 5. 2-points of contact offer high contact reliability.









■Product Specifications

Rated curre	Power contact : 3A Signal contact : 0.3A	Operation temperature range	-40 to 85°C (Note 1)	Storage temperature range	-10 to 60°C (Note 2)
Rated volta	e 30V AC/DC	Operation humidity range	90% RH or below (Note 3)	Storage humidity range	90% RH or below (Notes 2 and 3)

Items	Specifications	Conditions
1. Insulation resistance	Minimum of $1000M\Omega$	Measured at 100V DC
2. Withstanding voltage	There shall be no flashover or dielectric breakdown.	150V AC for 1 minute
3. Contact resistance	Signal contact : $100mΩ$ max. Power contact : $30mΩ$ max.	Measured at 20mV AC, 1kHz, and 1mA
4. Vibration resistance	There shall be no instantaneous power failure lasting for a minimum of 1μ s.	Frequency: 10 to 55 Hz, Half amplitude: 0.75mm, in 3 axis directions for 10 cycles each (5 minutes/cycle)
5. Moisture resistance	Contact resistance : Signal contact : $100m\Omega$ max. Power contact : $30m\Omega$ max. Insulation resistance : $100M\Omega$ min.	Temperature: 40±2°C, Humidity: 90 to 95%, left as it is for 96 hours
6. Temperature cycle	Contact resistance : Signal contact : $100m\Omega$ max. Power contact : $30m\Omega$ max. Insulation resistance : $100M\Omega$ min.	(-55°C for 30 minutes → 5 to 35°C for 10 minutes → 85°C for 30 minutes → 5 to 35°C for 10 minutes) in 5 cycles
7. Mating durability	Contact resistance : 100mΩ max.	Mating times : 10 times
8. Soldering heat resistance	There shall be no dissolution of the resin part affecting the performance.	Reflow: according to the Recommended temperature profile Hand soldering: temperature of soldering iron at 350°C for within 3 seconds

Note 1: Includes temperature rise caused by current flow.

Note 2: Storage refers to long-term-storage of unused items before they are mounted on the PCB. Operating temperature / humidity range applies to the state of temporary storage such as non-powered after mounting on the

Note 3: Avoid a high humidity environment.

PCB, and during transportation, etc.

■Materials / Finish

Product	Part	Material	Finish	UL specification
Receptacle Header	Insulator	LCP	Black	UL94V-0
	' Signal contact		Cold plated	
	Power contact	Phosphor bronze	Gold plated	

■Product Number Structure

Refer to the chart below when determining the product specifications from the product number. Please select from the product numbers listed in this catalog when placing orders.

Receptacle

 $\frac{\mathsf{BM}}{\bullet} \frac{29\mathsf{B}}{\bullet} \frac{0.6}{\bullet} - \frac{*}{\bullet} \frac{\mathsf{DS}}{\bullet} \frac{2}{\bullet} - \frac{0.35}{\bullet} \frac{\mathsf{V}}{\bullet} \frac{(**)}{\bullet}$


1 Series Name : BM	6 Connector type DS : Receptacle	Packaging
2 Series No. : 29B	Number of Power Contacts : 2	(51): Emboss tape packaging (20,000 pcs/reel)
3 Stacking height	Contact Pitch : 0.35mm	(53) : Emboss tape packaging
4 Number of Signal Contacts: 2, 4, 6, 24	Terminal shape V : Straight SMT	(1,000 pcs/reel)

•Header


Series Name : BM	6 Contact Pitch: 0.35mm
2 Series No. : 29B	▼ Terminal shape V : Straight SMT
3 Number of Signal Contacts : 2, 4, 6, 24	8 Packaging
4 Connector type DP : Header	(51): Emboss tape packaging (20,000 pcs/reel)
Number of Power Contacts : 2	(53): Emboss tape packaging (1,000 pcs/reel)

■Receptacle





◆Recommended PCB pattern diagram




Port No	HRS No.	No. of Contacts		۸	В		Ъ	Е
Part No.	THO NO.	Signal	Power	^	Ь		ן ט	_
BM29B0.6-2DS/2-0.35V(**)	673-7001-0 **	2	2	2.46	0.7	_	2.08	0.98
BM29B0.6-4DS/2-0.35V(**)	673-7063-0 **	4	2	2.81	1.09	0.35	2.43	1.33
BM29B0.6-6DS/2-0.35V(**)	673-7003-0 **	6	2	3.16	1.44	0.7	2.78	1.68
BM29B0.6-24DS/2-0.35V(**)	673-7053-0 **	24	2	6.31	4.59	3.85	5.93	4.83

Note 1: Please place your orders for full reel quantities of embossed tape packages.


Note 2: This connector has no polarity.

■Header





◆Recommended PCB pattern diagram





Recommended metal mask thickness: $100\mu m$, Aperture ratio: 80%

Unit: mm

Part No.	HRS No.	No. of C	Contacts	_	G	Н
Fait No.		Signal	Power	F	G	
BM29B-2DP/2-0.35V(**)	673-7002-0 **	2	2	1.81	0.77	_
BM29B-4DP/2-0.35V(**)	673-7064-0 **	4	2	2.16	1.12	0.35
BM29B-6DP/2-0.35V(**)	673-7004-0 **	6	2	2.51	1.47	0.7
BM29B-24DP/2-0.35V(**)	673-7052-0 **	24	2	5.66	4.62	3.85


Note 1: Please place your orders for full reel quantities of embossed tape packages.

Note 2: This connector has no polarity.

●Embossed Tape Dimensions (conforms to JIS C 0806)

●Receptacle

Reel dimensions





Unit: mm

Part No.	HRS No.	No. of Contacts		1	М	NI	0
Part No.		Signal	Power	L	IVI	IN	Q
BM29B0.6-2DS/2-0.35V(**)	673-7001-0 **	2	2	5.5	12	13.5	17.5
BM29B0.6-4DS/2-0.35V(**)	673-7063-0 **	4	2	5.5	12	13.5	17.5
BM29B0.6-6DS/2-0.35V(**)	673-7003-0 **	6	2	5.5	12	13.5	17.5
BM29B0.6-24DS/2-0.35V(**)	673-7053-0 **	24	2	7.5	16	17.4	21.4

Header

Reel dimensions






Unit: mm

Part No.	HRS No.	No. of Contacts		Т	U	W	Х
T dit ito:		Signal	Power	•		"	, ,
BM29B-2DP/2-0.35V(**)	673-7002-0 **	2	2	5.5	12	13.5	17.5
BM29B-4DP/2-0.35V(**)	673-7064-0 **	4	2	5.5	12	13.5	17.5
BM29B-6DP/2-0.35V(**)	673-7004-0 **	6	2	5.5	12	13.5	17.5
BM29B-24DP/2-0.35V(**)	673-7052-0 **	24	2	7.5	16	17.4	21.4

Precautions




Notes when mating connector

Be sure to mate this product manually.

Mating procedure

1) Align the connector at the guide.


A guide rib (tapered metal) is provided on the outer wall of the connector for mating support. Align the connector to this guide rib.



2) The connector enters automatically.

The connector slightly lowers when aligned correctly.

Find the guide by moving the connector in the X and Y directions.



3) Once aligned, mate the connector fully.

The connector becomes parallel when aligned. You cannot move it laterally and longitudinally.


4) Confirm the mated connector.

If incorrectly mated, remove, and mate it again.

Notes when unmating connector


1) Vertical direction

When removing the connector, remove it vertically. Number of contacts, FPC thickness, or other factors may make the vertical removal difficult.



2) Longitudinal removal

Remove the connector in the pitch direction in a slanted manner.




3) Lateral removal

Pull out the tip end of the FPC in the vertical direction. Applying a large force horizontally could deform the contacts.



4) Evaluate the mated state for thin FPCs.

Connector breakage or peeling off at soldering area could occur if the FPC does not have enough rigidity, please check the action in advance on the same type of FPC.



USA:

HIROSE ELECTRIC (U.S.A.), INC. HEADQUARTERS CHICAGO OFFICE

2300 Warrenville Road. Suite 150. Downers Grove, IL 60515 Phone: +1-630-282-6700 http://www.hirose.com/us/

USA:

HIROSE ELECTRIC (U.S.A.), INC. BOSTON OFFICE

300 Brickstone Square Suite 201, Andover, MA 01810

Phone: +1-978-662-5255

GERMANY:

HIROSE ELECTRIC EUROPE B.V. NUREMBERG OFFICE

Neumeyerstrasse 22-26, 90411 Nurnberg

Phone: +49-911 32 68 89 63 Fax: +49-911 32 68 89 69 http://www.hirose.com/eu/

UNITED KINGDOM:

HIROSE ELECTRIC EUROPE BV (UK BRANCH)

4 Newton Court, Kelvin Drive, Knowlhill,

Milton Keynes, MK5 8NH Phone: +44-1908 202050 Fax: +44-1908 202058 http://www.hirose.com/eu/

HIROSE ELECTRIC (CHINA) CO., LTD. SHENZHEN BRANCH

Room 09-13, 19/F, Office Tower Shun Hing Square, Di Wang Commercial Centre, 5002 Shen Nan Dong Road, Shenzhen City, Guangdong Province, 518008

Phone: +86-755-8207-0851 Fax: +86-755-8207-0873 http://www.hirose.com/cn/

KORFA:

HIROSE KOREA CO.,LTD.

143, Gongdan 1-daero, Siheung-si, Gyeonggi-do, 15084, Korea Phone: +82-31-496-7000 Fax: +82-31-496-7100 http://www.hirose.co.kr/

HIROSE ELECTRIC SINGAPORE PTE. LTD. BANGALORE LIAISON OFFICE

Unit No-403, 4th Floor, No-84, Barton Centre, Mahatma Gandhi (MG) Road, Bangalore 560 001, Karnataka, India

Phone: +91-80-4120 1907 Fax: +91-80-4120 9908 http://www.hirose.com/sg/

USA:

HIROSE ELECTRIC (U.S.A.), INC. SAN JOSE OFFICE

2841 Junction Ave. Suite 200 San Jose, CA, 95134 Phone: +1-408-253-9640 Fax: +1-408-253-9641 http://www.hirose.com/us/

THE NETHERLANDS: HIROSE ELECTRIC EUROPE B.V.

Hogehillweg #8 1101 CC Amsterdam Z-0

Phone: +31-20-6557460 Fax: +31-20-6557469 http://www.hirose.com/eu/

GERMANY:

HIROSE ELECTRIC EUROPE B.V. HANOVER OFFICE

Bayernstr. 3, Haus C 30855 Langenhagen, Germany

Phone: +49-511 97 82 61 30 Fax: +49-511 97 82 61 35 http://www.hirose.com/eu/

CHINA:

HIROSE ELECTRIC (CHINA) CO., LTD. (SHANGHAI, HEADQUARTERS)

18, Enterprise Center Tower 2, 209# Gong He Road, Jing'an District, Shanghai, CHINA 200070

Phone: +86-21-6391-3355 Fax: +86-21-6391-3335 http://www.hirose.com/cn/

HONG KONG:

HIROSE ELECTRIC HONGKONG TRADING CO., LTD.

Room 1001, West Wing, Tsim Sha Tsui Centre, 66 Mody Road, Tsim Sha Tsui East, Kowloon, Hong Kong

Phone: +852-2803-5338 Fax: +852-2591-6560 http://www.hirose.com/hk/

SINGAPORE:

HIROSE ELECTRIC SINGAPORE PTE. LTD.

03, Anson Road, #20-01, Springleaf Tower, Singapore 079909

Phone: +65-6324-6113 Fax: +65-6324-6123 http://www.hirose.com/sg/

MALAYSIA:

PENANG REPRESENTATIVE OFFICE

73-3-1, Ideal@The One, Jalan Mahsuri, Bayan Lepas Penang, 11950, Malaysia Phone: +604-648-5536 http://www.hirose.com/sg/

USA:

HIROSE ELECTRIC (U.S.A.), INC. DETROIT OFFICE (AUTOMOTIVE)

17197 N. Laurel Park Drive. Suite 253.

Livonia, MI 48152 Phone: +1-734-542-9963 Fax: +1-734-542-9964 http://www.hirose.com/us/

HIROSE ELECTRIC EUROPE B.V. GERMAN BRANCH

Schoenberastr. 20, 73760 ostfildern Phone: +49-711-456002-1 Fax: +49-711-456002-299 http://www.hirose.com/eu/

FRANCE:

HIROSE ELECTRIC EUROPE B.V. PARIS OFFICE

130 Avenue Joseph Kessel, Bat E, 78960 Voisins le Bretonneux, France

Phone: +33-1-85764886 Fax: +33-1-85764823 http://www.hirose.com/eu/

CHINA:

HIROSE ELECTRIC (CHINA) CO.,LTD. BEIJING BRANCH

A1001, Ocean International Center, Building 56# East 4th Ring Middle Road, ChaoYang District, Beijing, 100025

Phone: +86-10-5165-9332 Fax: +86-10-5908-1381 http://www.hirose.com/cn/

HIROSE ELECTRIC TAIWAN CO., LTD.

103 8F, No.87, Zhengzhou Rd., Taipei

Phone: +886-2-2555-7377 Fax: +886-2-2555-7355 http://www.hirose.com/tw/

INDIA:

HIROSE ELECTRIC SINGAPORE PTE, LTD, DELHI LIAISON OFFICE

Office NO.552, Regus-Green Boulevard, Level5, Tower C, Sec62, Plot B-9A, Block B, Noida, 201301, Uttar Pradesh, India

Phone: +91-12-660-8018 Fax: +91-120-4804949 http://www.hirose.com/sg/

THAILAND:

BANGKOK OFFICE (REPRESENTATIVE OFFICE)

Unit 4703, 47th FL., 1 Empire Tower, South Sathorn Road, Yannawa, Sathorn, Bangkok 10120 Thailand

Phone: +66-2-686-1255 Fax: +66-2-686-3433 http://www.hirose.com/sg/



HIROSE ELECTRIC CO.,LTD.

2-6-3, Nakagawa Chuoh, Tsuzuki-Ku, Yokohama-Shi 224-8540, JAPAN TEL: +81-45-620-3526 Fax: +81-45-591-3726

http://www.hirose.com

http://www.hirose-connectors.com

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

Hirose Electric:

 $\underline{\mathsf{BM29B\text{-}2DP/2\text{-}0.35V(53)}} \ \underline{\mathsf{BM29B0.6\text{-}2DS/2\text{-}0.35V(51)}} \ \underline{\mathsf{BM29B\text{-}2DP/2\text{-}0.35V(51)}} \ \underline{\mathsf{BM29B0.6\text{-}2DS/2\text{-}0.35V(53)}}$